# Cordless Cellular Shade Installation Instructions

### Fig. 1

# MEASURING YOUR WINDOW

Choose whether you would like your Cellular Shade inside the window recess (IN) or to cover the window frame

### Inside Mount:

Fig. 2

1) Measure the width and the height of the window opening. Approx. 13mm is required for mounting depth inside the window frame. (See Fig. 1)

## Outside Mount:

1) Measure the area of the window you want to cover, including any overlap on the surrounding wall (See Fig. 2)

# **EASY INSTALLATION**

Fig. 3



1) Mounting the brackets (Fig. 3) will depend on whether you want the shade to be INSIDE or OUTSIDE the window · frame,


Fig. 4

For INSIDE: Mount the brackets to the top of the window frame and use the top bracket holes to secure brackets (See Fig. 4) For OUTSIDE: Center the shade over the window opening at the desired height and use the rear bracket holes to secure brackets. (See Fig. 5)





2) Position the brackets approx.13-26mm from the end of the headrail, ensuring that if you have a wide shade the brackets are evenly spaced so they do not interfere with the shade operation. Make certain the brackets are aligned with each other, you may find difficulty securing the headrail into the brackets if they are not alianed.



Lift the headrail into position so that the front edge of the bracket is under the inner front edge of the headrail. (See Fig. 6)

Push the headrail upwards until the flexible tab at the bottom of each bracket snaps onto the back of the

Fig. 6


5) Check carefully to assure that each bracket is properly secured.



# SHADE OPERATION

For best operation, the center of the bottom rail should be used when raising or lowering the shade. Simply grasp the center of the bottom rail and pull or push the shade to the desired length and release. (See Fig. 7 & 8)

To Lower Cellular Shade:



To Raise Cellular Shade:

